

## LED Wireless Charging Speaker

# S301

Bluetooth version V5.3



EN

### Instructions for using the wireless charging speaker



#### Wireless charger use: plug in the charger to automatically turn on

- ☎ Long press power / short press light switch
- 🔊 Long press function switch BT / NS / FM mode, short press pause / play
- ⌚ Short press the timing 15/30/60
- 🔊 Short press the next song, long press to add the volume
- ⏮ Short press the last song, long press to reduce the volume
- 🕒 Alarm clock setting
- 🕒 Clock Settings

### technical parameter:

Wireless charging power: 15W  
Wireless version: 5.3  
Wireless name: S301  
Output power: 5W\*2  
Wireless frequency: 2.4GHZ-2.48GHZ  
Transmission distance: 10 meters  
Frequency sound range: 50 HZ-20 KHZ  
Sigto noise ratio of whole machine: greater than 75 db  
Built-in lithium battery voltage: 3.7V charging input: DC5V / 500MA  
Product size: 180\*100\*90mm  
Product weight: 780g  
Speaker battery: 1200 mAh

### Operation description of the key function

- 一、 Start up: long press the start button for two seconds to start up, start up the default heating light
- 二、 The Wireless function is used for use:
  1. This audio supports the use of Wireless devices with A2DP function, boot default into the Wireless mode, Wireless indicator blue light shining, accompanied by voice prompt, when the stereo is waiting for pairing connection, only in this state, can be paired and connected with the Wireless audio.

### 2. Mobile phone connection

The first step is to open the phone Wireless setting switch in the phone Settings and click the search device  
The second step, when the available device displays the S301 character indicating that the phone finds the Bluetooth stereo, click S301 to enter the pairing mode. After the phone is successfully paired with the stereo, there will be a voice prompt and display the connected.

### 三、 TWS couplet function (this function is suitable for Wireless mode only)

When you have two S301 Wireless speakers, by long pressing one of the keys to match, Wireless connected to each other, the two speakers will automatically become the left and right sound channels to produce stereo surround sound effect, achieving real wireless stereo.

### Light use

- 1) The S301 Wireless speaker is equipped with 12 lighting effects
- 2) Start the default warm lamp effect of the equipment, and press the light key to adjust the light

### FM radio to use:

M key long press to switch to the FM function, connect the charging cable to the product type-c interface as a radio antenna, the other end does not need to connect any equipment, through the pause button to enter the station automatic search and automatically save, the cable station through + - saved station selection.

### TF card / U disk function for use:

By inserting the TF card / U disk into the card slot, the corresponding voice prompt will

appear. The product will automatically read the audio file in the card and play it. The user can use the voice to control the music with the speaker + -button.

### Clock Setting

Press the time key to enter the clock / minute setting, press / adjust the hour / minute + / 🔊 / - / 🔊

### Alarm clock setting

+ / 🔊 / - / 🔊 Press the alarm button to enter the clock / minute setting, press / adjust the hour / minute, press the alarm key and then press / select your favorite alarm, there are 7 groups of alarm bells, and finally press the alarm key to open the alarm clock (the alarm mark appears on the screen after successful setting). When the alarm rings, press any key to close the alarm. When no one turns off, the alarm will automatically turn off for 1 minute (the alarm will ring normally in the shutdown state, please cancel the alarm clock without the need)  
Cancel alarm setting: long press the alarm key (the alarm sign disappears on the screen after successful cancellation)

### White noise use:

M to switch to white noise mode, press / choose your favorite sleep music + / 🔊 / - / 🔊

### Safety Instructions:

1. Do not expose the product into the water or humid areas, such as bathrooms.
2. Please do not hit or drop the product hardly to avoid manual damage.
3. When not in use for a long time, please turn off the power.

### Warranty and After Sales Service :

If you have any questions during use, please feel free to contact us, we are responsible for every customer.

### הגדרת השעון

לחץ על כפתור השעה כדי להיכנס להגדרות השעה והדקות.  
השתמש בכפתורים המתאימים כדי להגדיל או להקטין את השעה והדקות.

### הגדרת שעון מעורר

לחץ על כפתור השעון המעורר כדי להיכנס להגדרות השעה והדקות.  
לאחר הגדרת השעה והדקות, בחר את צליל המעורר המועדף עליך מבין 7 האפשרויות.

### הפעלת השעון המעורר

לחץ על כפתור השעון המעורר כדי להפעיל את השעון. סמל השעון המעורר יופיע על המסך.

**כיבוי השעון המעורר** לחץ על כל כפתור כדי לכבות את הצלצול. אם לא תכבה את הצלצול, הוא ייפסק אוטומטית לאחר דקה.

**ביטול השעון המעורר** לחץ לחיצה ארוכה על כפתור השעון המעורר כדי לבטל את השעון המעורר לחלוטין. סמל השעון המעורר ייעלם מהמסך.

### שימוש ברעש לבן

לחץ על כפתור ה-M כדי להפעיל את מצב הרעש הלבן.  
בחר את צליל הרעש הלבן המועדף עליך.

### הוראות בטיחות

- אל תחשוף את המוצר למים או לאזורים לחים  
- הימנע מנפילות ומכות חזקות על המוצר

- כבה את המכשיר כאשר אינו בשימוש למשך זמן ממושך.

### אחריות ושירות לקוחות

במידה ויש לך שאלות או בעיות, צור איתנו קשר. אנו נשמח לעזור לך.

### חיבור לטלפון סלולרי

פתחו את הגדרות הבלוטות' בטלפון שלכם והפעילו את החיפוש אחר מכשירי BLUETOOTH ברשימת המכשירים הזמינים, חפשו את המכשיר שמוצג כ S301 ובחרו בו כדי להתחבר. לאחר ההתחברות, תשמעו הודעה קולית ותוצג הודעה על ההתחברות.

### פונקציית סטריאו אלחוטית TWS

קיצור של True Wireless Stereo כלומר סטריאו אלחוטי אמיתי.  
אם יש לך שני רמקולים זהים, תוכל לחבר אותם זה לזה באופן אלחוטי כדי ליצור חווית שמע סטריאופונית.  
לחץ לחיצה ארוכה על כפתור ההתאמה באחד הרמקולים. שני הרמקולים יתאמו זה לזה באופן אוטומטי, והרמקול השמאלי והימני יוקצו אחד לשני אוטומטית.

### שימוש בתאורה

הרמקול מציע 12 אפקטים תאורה שונים.  
לחץ על כפתור התאורה כדי לשנות בין אפקטים שונים.

### רדיו FM

לחץ לחיצה ארוכה על כפתור ה-M כדי להפעיל את רדיו ה-FM.  
חבר את כבל הטעינה (חיבור Type-C) לרמקול. הכבל ישמש כאנטנה, הצד השני של הכבל לא צריך להיות מחובר.  
לחץ על כפתור ההשחיה כדי לחפש תחנות באופן אוטומטי ולשמור אותן. השתמש בכפתורים להעלאה והורדה של עוצמת הקול כדי לבחור תחנה שמורה.

### כרטיס זיכרון/דיסק און קי:

הכנס כרטיס זיכרון או דיסק און קי לחרוץ המתאים. הרמקול יזהה את המכשיר ויתחיל לנגן את הקבצים השמורים בו באופן אוטומטי. אפשר לשלוט על המוזיקה בעזרת פקודות קוליות או על ידי לחיצה על כפתור '+' ברמקול.

### פרמטרים טכניים

הספק טעינה אלחוטית: W15  
גרסת BLUETOOTH : 5.3  
שם BLUETOOTH: S301  
הספק יציאה: 5W\*2  
תדר אלחוטי: 2.4-2.48GHZ  
טווח שידור: 10 מטרים  
טווח תדרים של צליל: 50 KHZ – 20 HZ  
יחס אות לרעש: מעל 75 db  
מתח סוללת הליתיום הפנימית: כניסת טעינה DC5V / 500MA  
מידות המוצר: 180X100X90 מ"מ  
משקל המוצר: 780g  
סוללת המוצר: 1200mAh

### פונקציות המפתח

הפעלה: לחיצה ארוכה על כפתור ההפעלה למשך שתי שניות  
תפעיל את המכשיר ותדליק את תאורת החימום המוגדרת כברירת מחדל.

### פונקציית אלחוט

המכשיר תומך במכשירים אלחוטיים התומכים בפרוטוקול A2DP. בהפעלה, המכשיר ייכנס אוטומטית למצב אלחוטי.  
נורית ה-BLUETOOTH תהבהב, ותשמע הנהייה קולית המציינת שהמכשיר מוכן להתחבר למכשיר אלחוטי אחר. רק במצב זה ניתן לחבר את המכשיר למכשיר אלחוטי אחר.

### הוראות שימוש לרמקול אלחוטי נטען



- ☎ לחיצה ארוכה מפעילה את ברמקול/ לחיצה קצרה מחליפה את האור
- 🔊 לחיצה ארוכה על כפתור החלפת מצב תאפשר לך לעבור בין מצבי בלוטות', חדשות, רדיו FM/ לחיצה קצרה תעצור או תתחיל את ההפעלה.
- ⌚ הגדרת טיימר: לחיצה קצרה על כפתור הטיימר תאפשר לך לבחור בין 15, 30 או 60 דקות.
- 🔊 לחיצה קצרה על כפתור השיר הבא תעביר לשיר הבא. לחיצה ארוכה תעלה את עוצמת הקול.
- 🔊 לחיצה קצרה על כפתור השיר הקודם תעביר לשיר הקודם. לחיצה ארוכה תוריד את עוצמת הקול.
- ⌚ הגדרת שעון מעורר: תאפשר לך להגדיר שעה ספציפית להשמעת צלצול.
- 🕒 הגדרת שעון: תאפשר לך להגדיר את השעה הנוכחית.

### רמקול אלחוטי עם טעינה אלחוטית ומנורת LED

# S301

גרסת V5.3 Bluetooth



HE